

NOVA POWERSTAT

Replacement

USER INSTRUCTIONS - PLEASE READ CAREFULLY

- 1) Unplug the processor, allow to cool fully and then drain all the solution slots by way of the drain taps. Never attempt to lift a processor full of liquids. Once the slots are empty, tip the unit up into a sink to empty the water cores.
- 2) Remove the heater cable from the location holes on the front of the processor. Position the processor on its back so that the taps and pipes or heater point to the ceiling. This allows better access to the heater boxes.
- 3) The heater will initially be quite tight and so it is best to gently prise it out with the aid of a screwdriver. Slide the crewdriver under the black box and with restrained force, gently prise the box upward a little at a time. Once the box is out about 1" (3cm) then you can grasp the heater box with your thumb and forefinger and firmly pull and twist. until the whole unit has come out in one piece (with the glass tube attached). If there are two heaters, then repeat procedure but do both heaters in turn a little at a time so that they can be removed as a pair together.
- 4) Take the black rubber grommet (supplied) and smear a small amount lubricating grease around the inside of it. **DO NOT GREASE THE OUTSIDE OF THE GROMMET!**
- 5) Insert the grommet into the heater hole on the front of the processor.
- 6) Take the new heater unit and smear a small amount of lubricating grease around the end 8 - 10 cm of the glass tube(s).
- 7) Locate the heater in the grommet on the processor and push and twist it with restrained force until it is fully inserted.
NOTE:- There is a locating glass support about 15cm inside the water core that the heater must pass through very carefully. **DO NOT** force the heater in without locating the glass in the holes.
- 8) Re-thread the cable through the location holes at the front of the unit or use a cable tie supplied.
- 9) Ensure that all water core(s) and solution slots, switch on and reset your working temperature as described in your original processor instructions.

Nova Darkroom Equipment
Unit 1A, Harris Road
Wedgnock Industrial Estate
Warwick, CV34 5JU
England
Telephone:- 01926 403090
Fax:- 01926 499992



